




PLL SECTION ALIGNMENT POINTS




RECEIVER SECTION ALIGNMENT POINTS





PLL SECTION ALIGNMENT POINTS



78 MHz LOCAL SECTION ALIGNMENT POINTS



METER (BATTERY CHECK),
SQUELCH PRESET ALIGNMENT POINTS



- | | |
|---------|---------|
| VR 2002 | CV 2002 |
| VR 2001 | CV 2001 |
| TC 2004 | |
| J 3003 | |
| P 1002 | P 2002 |
| J 2002 | J 1007 |
| P 2004 | T 1019 |
| TC 2003 | VR 1001 |
| TC 2002 | VR 1009 |
| J 2001 | T 1018 |
| P 2003 | VR 1005 |
| TC 1003 | T 1017 |
| TC 1005 | VR 1002 |
| TC 1004 | T 1016 |
| R 1119 | TC 1002 |
| VR 1006 | D 1033 |
| VR 1013 | T 1015 |
| VR 1010 | TP 1003 |
| VR 1007 | L 1009 |

TRANSMITTER SECTION ALIGNMENT POINTS

